


# Concrete Waste Management



## NOTES:

1. Residue from saw cutting, coring, and grinding operations shall be picked up by means of a vacuum device. Residue shall not be allowed to flow across the pavement and shall not be left on the surface of the pavement. Vacuumed slurry residue shall be disposed of properly.
2. Temporary concrete washout facilities shall be located a minimum of 15 m (50 ft) from storm drain inlets, open drainage facilities, and watercourses, unless determined infeasible by the RE. Each facility shall be located away from construction traffic or access areas to prevent disturbance or tracking.
3. A sign shall be installed adjacent to each washout facility to inform concrete equipment operators to utilize the proper facilities. The sign shall be installed as shown on the plans.
4. Temporary concrete washout facilities shall be constructed above grade or below grade at the option of the Contractor. Temporary concrete washout facilities shall be constructed and maintained in sufficient quantity and size to contain all liquid and concrete waste generated by washout operations.
5. Perform washout of concrete mixers, delivery trucks, and other delivery systems in designated areas only.
6. Wash concrete only from mixer chutes into approved concrete washout facility. Washout may be collected in an impermeable bag or other impermeable containment devices for disposal.
7. Once concrete wastes are washed into the designated area and allowed to harden, the concrete shall be broken up, removed, and disposed of properly.
8. Plastic lining material shall be a minimum of 10-mil polyethylene sheeting and shall be free of holes, tears or other defects that compromise the impermeability of the material. Liner seams shall be installed in accordance with manufacturers' recommendations.
9. Holes, depressions or other ground disturbance caused by the removal of the temporary concrete washout facilities shall be backfilled and repaired.
10. Existing facilities must be cleaned, or new facilities must be constructed and ready for use once the washout is 75% full.
11. Straw bales must be TRPA approved or straw wattles may be used.

